



Document - CS51562

Document Information

Type	Article
Date Created	28-Feb-2012
Date Last Updated	10-Aug-2017

Document Details

Title	How to convert a solid part into skeleton model in Creo Parametric
Description	<ul style="list-style-type: none"> How to convert a solid part into skeleton model ?
Applies To	<ul style="list-style-type: none"> Creo Parametric 1.0 to 4.0
Cause	
Resolution	<ul style="list-style-type: none"> Not part of Creo Parametric functionality To request this functionality, refer to Product Ideas @ PTC Community Workaround 1: <ol style="list-style-type: none"> File > New > Assembly > Ok > Create > Skeleton Model > Ok > Copy from Existing > Browse > select the file > Open > Ok Workaround 2: <ol style="list-style-type: none"> File > New > Assembly > Ok > Create > Skeleton Model > Ok > Empty > Ok Open the newly created skeleton part Get Data > Merge/Inheritance > Open a model which geometry will be contained

SPR Information

Related Documents

Type	Number	Status	Description
------	--------	--------	-------------