

Per Pro Help

STATES.

hole profile. These hole charts consist of industry-standard thread type and custom charts to meet your specific design needs. Note that you must not edit diameter information. Pro/ENGINEER provides hole charts and you can create "Thread type box-Contains hole charts that enable you to define the Standard the provided hole charts. The following hole charts are provided:"

NPTF

SNC

ISO_7/1