


# モデルが読込めないのですが、何か設定が不足していますでしょうか？



**Creo Parametric 7.0.8.0**

SimLab 2022 - Update Configuration

### Select Creo Version

Select a Creo version and its installation directory if you need Creo geometry access in SimLab.

**Altair SimLab**

Select a Creo Version :

- Creo 2.0
- Creo 3.0
- Creo 4.0
- Creo 5.0
- Creo 6.0
- Creo 7.0**
- Creo 8.0

Select Creo Startup File :

**Assembly Browser**

'0' Models

**Output Window**

```

*****
****
Pro ENGINEER Reader
*****
****
Copyright
Altair Engineering
All rights reserved.
*****
****

ProE Process started ...
ProE Process complete ...
    
```

Y Z X