



3D view pipe flow direction is possible.



In drawing why the pipe flow direction is not possible?

It's there any option to show flow direction in drawing view, and while printing also.
If any possible please let me know it.