

When I select Recursive it keeps adding detail 1 for a second time



REV	SHEET	DETAIL	QTY	DESCRIPTION
		I	1	WELDMENT - RACK
		I	1	WELDMENT - RACK
		IA	2	TUBE, SQUARE
		IB	2	TUBE, SQUARE
		IC	2	TUBE, SQUARE
		ID	2	TUBE, SQUARE
		IE	2	FORK POCKET - WIDTH
		IF	2	FORK POCKET - LENGTH
		IG	1	TUBE, SQUARE
		IH	4	TUBE, SQUARE
		IJ	6	TUBE, SQUARE
		IK	4	TUBE, SQUARE
		IM	12	TUBE, SQUARE
		IN	4	TUBE, SQUARE
		IP	4	TUBE, SQUARE
		IQ	10	TUBE, SQUARE
		IR	1	TUBE, ROUND, MECHANICAL
		IT	8	STACKING CAP 2.500"
		IU	1	FLAT BAR
		IV	2	FLAT BAR
		IW	6	FLAT BAR
		IX	6	FLAT BAR
		IZA	1	WELDMENT
		IZA1	1	FLAT BAR
		IZA2	1	FLAT BAR
		IZA3	1	FLAT BAR
		IZA4	1	BULL NOSE

REV	SHEET	DETAIL	QTY	DESCRIPTION
		I	1	WELDMENT - RACK
		IA	2	TUBE, SQUARE
		IB	2	TUBE, SQUARE
		IC	2	TUBE, SQUARE
		ID	2	TUBE, SQUARE
		IE	2	FORK POCKET - WIDTH
		IF	2	FORK POCKET - LENGTH
		IG	1	TUBE, SQUARE
		IH	4	TUBE, SQUARE
		IJ	6	TUBE, SQUARE
		IK	4	TUBE, SQUARE
		IM	12	TUBE, SQUARE
		IN	4	TUBE, SQUARE
		IP	4	TUBE, SQUARE
		IQ	10	TUBE, SQUARE
		IR	1	TUBE, ROUND, MECHANICAL
		IT	8	STACKING CAP 2.500"
		IU	1	FLAT BAR
		IV	2	FLAT BAR
		IW	6	FLAT BAR
		IX	6	FLAT BAR
		IZA	1	WELDMENT

Menu Manager X

TBL REGIONS

Attributes

REGION ATTR

Duplicates

No Duplicates

No Dup/Level

Recursive

Flat

Min Repeats

Start Index

No Start Idx

Bln By Part

Bln By Comp

Cable Info

No Cbl Info

Done/Return

Menu Manager X

TBL REGIONS

Attributes

REGION ATTR

Duplicates

No Duplicates

No Dup/Level

Recursive

Flat

Min Repeats

Start Index

No Start Idx

Bln By Part

Bln By Comp

Cable Info

No Cbl Info

Done/Return